




NO POWER




NOT SHAVING



CALIBRATION



MACHINE LEAKING



MACHINE TOO LOUD

